GW0005 MOBILE GREENWALL

Watering Kit included



Thank you for purchasing a Holman Mobile GreenWall.

Please keep your receipt as proof of purchase to validate the 1 year product warranty.

Please read this instruction manual prior to use.



GLOSSARY

CONTENT LIST


- 4x Long Back Poles 2x Short Front Poles 4x Wheels 12x Clips 9x Small Pots 9x Small Pot Mats 2x Large Pots 2x Large Pot Mats 12x Inline Drippers
- 1x End Dripper
- 1x 10 metre, 4mm Poly Tube

1. LOCATION


The benefit of the Mobile GreenWall is that it can be easily moved around accordingly to the amount of sunlight the different types of plants require. This has a big bearing on what will grow successfully. Also think about where your water source will be and how easily you can run a hose from that tap.

2. WHEELS

Screw the wheels into the end of the long back and short front poles.








3. FRAME CLIPS

Use the clips to attach the wire frames onto the poles. Clip them onto the pole and lock arrows are pointing upwards.


4. WIRE FRAMES



Slide the wire frames onto the clips. The attachments have a slight v-shape. The wider part has to point downwards.

Attach the pot holder onto the long back poles using the clips. You can decide the margin between bars by using different grooves.

5. HANGING THE POTS




TIP: Plant the pots before installing.

Once the pots are planted they are ready to be hung onto the panel.

Each pot has a flat hook at the rear. This can be hooked along the frame as shown.

6. IRRIGATION SETUP



PART 1: Once all the pots are connected to the frame you are ready to install the irrigation.

- 1) Run the poly tube through the groove at the back of the pots.
- 2) Leave some slack when running the tube around the pots.
- 3) Cut the poly tube and insert an inline dripper. To continue the chain, attach the remaining poly tube to the other end of the inline dripper (ensure you are placing the dripper above each pot).
- 4) In the last pot, finish the poly tube with the end dripper.

TROUBLE SHOOTING



PART 2:

- 1) Connect a garden hose or poly pipe to the hose adapter.
- 2) Connect a Holman Tap Timer to your tap for automatic watering.
- 3) Attach the other end of the garden hose or poly pipe to the Tap Timer.
- 4) Turn on the water and test the drippers.



TAP TIMER

WARRANTY

them into position (grooves). Make sure that the

We suggest installing a Holman Tap Timer to automatically and accurately water your GreenWall. Schedule the tap timer to meet your required watering, this will then ensure your plants remain hydrated and healthy and encourage the best result for the growth of your GreenWall.

HINT: Watering for short intervals 3 or 4 times a day is recommended for the best result.

For tips and tricks on watering and plant selection visit our website.

https://www.holmanindustries.com.au/greenwall-vertical-gardening/

Drippers are not working properly

If some drippers are not working well, you can unscrew or slightly loosen the cap of the dripper. Remember to connect the pressure reducer and filter to the outlet of the tap. It is very important to keep the water supplied to the drippers clean from dirt and grit.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

As well as your statutory rights referred to above and any other rights and remedies you have under any other laws relating to your Holman product, we also provide you with a Holman guarantee. Holman guarantees this product against defects caused by faulty workmanship and materials for the specified warranty duration for domestic use from the date of purchase. During this guarantee period Holman will replace any defective product. Packaging and instructions may not be replaced unless faulty.

In the event of a product being replaced during the guarantee period, the guarantee on the replacement product will expire after the warranty duration from the purchase date of the original product, not from the date of replacement.

To the extent permitted by law, this Holman Replacement Guarantee excludes liability for consequential loss or any other loss or damage caused to property of persons arising from any cause whatsoever. It also excludes defects caused by the product not being used in accordance with instructions, accidental damage, misuse, or being tampered with by unauthorised persons, excludes normal wear and tear and does not cover the cost of claiming under the warranty or transporting the goods to and from the place of purchase.

HOLMAN INDUSTRIES 11 Walters Drive, Osborne Park, WA 6017 Ph: 1300 716 188 www.holmanindustries.com.au